
Using Serial Communication

Method used to transfer data between two devices.






Serial Monitor & analogRead()


```
00
                  sketch_apr02a | Arduino 1.0.3
File Edit Sketch Tools Help
  sketch_apr02a §
// analogRead() & Serial.print()
int sensorValue = 0:
int sensorPin = A0;
void setup()
                                   Initializes the Serial
  Serial.begin(9600):
                                      Communication
  pinMode(AU, INPU)
void loop()
                                                 9600 baud data rate
  sensorValue = analogRead(A0);
  Serial.println(sensorValue);
  delay(100); // waits by about 0.1 sec
                                                   prints data to serial bus
```

This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

Serial Monitor & analogRead()



Analog Sensors 2 Pin Analog Sensors = var. resistor



Take two sensors -- Use the Serial Monitor and find the range of input values you get for each sensor.

MaxAnalogRead = _____

MinAnalogRead = _____



Analog Sensors

Examples:


Sensors	Variables
Mic	soundVolume
Photoresistor	lightLevel
Potentiometer	dialPosition
Temp Sensor	temperature
Flex Sensor	bend
Accelerometer	tilt/acceleration



Additional Serial Communication Sending a Message

```
void loop ( )
{
   Serial.print("Hands on ");
   Serial.print("Learning ");
   Serial.println("is Fun!!!");
}
```





Serial Communication: Serial Debugging

```
void loop()
   int xVar = 10;
   Serial.print ( "Variable xVar is " ) ;
                                                                    COM24
   Serial.println (xVar);
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                   Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                  Variable xVar is 10
                                                   ✓ Autoscroll
                                                                          No line ending V 9600 baud
```

Serial Communication: Serial Troubleshooting

```
void loop ( )
   Serial.print ("Digital pin 9: ");
   Serial.println (digitalRead(9));
                                                                   COM24
                                                  Digital pin 9: 1
                                                 Digital pin 9: 1
                                                 Digital pin 9: 1
                                                 Digital pin 9: 1
                                                  Digital pin 9: 1
                                                  Digital pin 9: 1
                                                  Digital pin 9: 1
                                                 Digital pin 9: 1
                                                 Digital pin 9: 1
                                                 Digital pin 9: 1
                                                  Autoscroll
                                                                         No line ending 😛 9600 baud
```